

# POWERFLEX®

PART NUMBER

**PFR5-4621**

DESCRIPTION

**REAR DIFF FRONT BUSH**

## INSTALLATION GUIDE

### Contents (parts per pack):

- 1 x bush
- 1 x stainless steel sleeve
- 1 x washer
- 1 x grease



*Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

*It is recommended that:*

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.

*All fasteners must be tensioned to manufacturer's torque settings.*

### Fitting Instructions:

1. Remove the original rear diff front bush from the subframe. Clean any rust and dirt from the hole.
2. Push the new bush into the subframe, the end with recessed facing outwards away from the diff.
3. Apply some of the supplied grease to the bore of the bush, push the stainless steel sleeve into the bush.
4. Refit the original washer that sits between the diff and bush.
5. Fit new washer into the recess on the outer face of the bush, refit the bolt and tighten.

